



34 Rundlett Hill Road • Unit 4 • Bedford, NH 03110
(603) 624-0090 • Fax (603) 668-4392 • Toll free (800) 601-9152

Customizing Your Partner Telephone

*All programming below can be done at each user's extension.

1. FEATURE 0 0
2. Press the button you wish to program and then one of the following:
 - a. For *Voice Mail*, press Left Intercom and 7 7 7
 - b. For *VM Transfer* press FEATURE 1 4
 - c. For *Redial*, press FEATURE 0 5
 - d. For *DND* (do not disturb), press FEATURE 01
 - e. For *Intercom + Extension*, press left intercom and the extension number
 - f. For paging (over telephones), press Left Intercom * 7 1
3. Repeat step 2 until all your buttons are programmed.
4. Once you are finished all programming, press FEATURE 0 0.